











Features

- Universal AC input / Full range (Withstand 300VAC surge input for 5 seconds)
- · Built-in active PFC function
- · High efficiency up to 93%
- Forced air cooling by built-in DC fan
- · Output voltage and constant current level programmable
- Built-in OR-ing FET, support hot swap (hot plug)
- · Active current sharing up to 8000W for one 19" rack shelf
- Built-in I²C interface, PMBus protocol (Optional CANBus protocol)
- Protections: Short circuit / Overload / Over voltage / Over temperature
- Optional conformal coating
- 5 years warranty

Front



















Applications

- · Industrial automation
- · Distributed power architecture system
- Wireless/telecommunication solution
- Redundant power system
- Electric vehicle charger system
- Constant current source system


GTIN CODE

MW Search: https://www.meanwell.com/serviceGTIN.aspx

Description

RCP-1600 is a 1.6KW single output rack mountable front end AC/DC power supply with a 1U low profile and a high power density up to 25W/inch³. This series operates for 90~264VAC input voltage and offers the models with the DC output mostly demanded from the industry. Each model is cooled by the built-in DC fan with fan speed control, working for the temperature up to 70°C. RCP-1600 provides vast design flexibility by equipping various built-in functions such as the PMBus and CANBus communication protocol, output programming, active current sharing (up to 24000W via three 19" rack shelves, RHP-1U), remote control, auxiliary power, alarm signal, etc. Maximum number that can be monitored by master controller in communication shall be 15 power supplies.

Model Encoding / Order Information



- X Note 1: 19" rack shelf, RHP-1U, available. Details available on http://www.meanwell.com/
- Mote 2: Control/Monitor unit, RKP-CMU1, available. Details available on http://www.meanwell.com/

Type	Communication Protocol	Note
Blank	PMBus protocol	In Stock
CAN	CANBus protocol	By request



SPECIFICATION


MODEL		RCP-1600-12	RCP-1600-24	RCP-1600-48		
	DC VOLTAGE	12V	24V	48V		
	RATED CURRENT	125A	67A	33.5A		
	CURRENT RANGE	0 ~ 125A	0 ~ 67A	0 ~ 33.5A		
	RATED POWER	1500W	1608W	1608W		
	RIPPLE & NOISE (max.) Note.2		200mVp-p	300mVp-p		
OUTPUT	VOLTAGE ADJ. RANGE Note.6		23.5 ~ 30V	47.5 ~ 58.8V		
DUIPUI						
	VOLTAGE TOLERANCE Note.4		±1.0%	±1.0%		
	LINE REGULATION	±0.5%	±0.5%	±0.5%		
	LOAD REGULATION	±0.5%	±0.5%	±0.5%		
	SETUP, RISE TIME	1500ms, 60ms/230VAC at full load				
	HOLD UP TIME (Typ.)	16ms / 230VAC at 75% load 10ms / 230VAC at full load				
	VOLTAGE RANGE Note.5	90 ~ 264VAC 127 ~ 370VDC				
	FREQUENCY RANGE	47 ~ 63Hz				
	POWER FACTOR (Typ.)	0.97/230VAC at full load				
NPUT	EFFICIENCY (Typ.)	88.5%	91%	93%		
• .		14A/115VAC 8A/230VAC	15A/115VAC 8.5A/230VAC			
	INRUSH CURRENT (Typ.)	COLD START 35A/230VAC				
	LEAKAGE CURRENT	< 1.5mA / 230VAC				
	EL MAGE GOMMENT	105 ~ 115% rated current				
	OVERLOAD		:::	ft O/D		
		**	<u> </u>	After O/P voltage falls, re-power on to recover		
PROTECTION	OVER VOLTAGE	15.75 ~ 18.75V	31.5 ~ 37.5V	63 ~ 75V		
		Protection type: Shut down o/p voltage, re-power on to recover				
	OVER TEMPERATURE	Shut down o/p voltage, recovers automatically after temperature goes down				
	OUTPUT VOLTAGE		able to 40 ~ 125% of nominal output volta	age(60~125% for 12V).		
	PROGRAMMABLE(PV) Note 6	Please refer to the Function Manual in following pages.				
	OUTPUT CURRENT	Adjustment of constant current level is allowable to 20 ~ 100% of rated current.				
FUNCTION	. ,	Please refer to the Function Manual in following pages.				
FUNCTION	REMOTE ON-OFF CONTROL	By electrical signal or dry contact Power ON:short Power OFF:open. Please refer to the Function Manual in following pages.				
	REMOTE SENSE	Compensate voltage drop on the load wiring up to 0.5V. Please refer to the Function Manual in following pages.				
	AUXILIARY POWER	5V @ 0.3A, 12V @ 0.8A				
	ALARM SIGNAL	Isolated TTL signal output for T-Alarm, AC-OK and DC-OK				
	WORKING TEMP.	-30 ~ +70°C (Refer to "Derating Curve")				
	WORKING HUMIDITY 20 ~ 90% RH non-condensing					
ENVIRONMENT	STORAGE TEMP., HUMIDITY	-40 ~ +85°C, 10 ~ 95% RH non-conde	nsing			
	TEMP. COEFFICIENT	±0.03%/°C (0 ~ 50°C)				
	VIBRATION	10 ~ 500Hz, 2G 10min./1cycle, 60min.	each along X, Y, Z axes			
	SAFETY STANDARDS	UL62368-1, CAN/CSA C22.2 No. 62368-1, TUV BS EN/EN62368-1, EAC TP TC 004 approved				
	WITHSTAND VOLTAGE	I/P-O/P:3KVAC I/P-FG:2KVAC O/		· · · · · · · · · · · · · · · · · · ·		
	ISOLATION RESISTANCE	I/P-O/P, I/P-FG, O/P-FG:100M Ohms /				
		1 11 011 , 111 1 0 , 011 1 0 . 100 111 0 111110 1				
	ISOLATION RESISTANCE	Parameter	Standard	Test Level / Note		
	ISOLATION RESISTANCE	Parameter Conducted	Standard BS EN/EN55032 (CISPR32)	Test Level / Note		
		Conducted	BS EN/EN55032 (CISPR32)	Class B		
	EMC EMISSION	Conducted Radiated	BS EN/EN55032 (CISPR32) BS EN/EN55032 (CISPR32)	Class B Class A		
		Conducted Radiated Harmonic Current	BS EN/EN55032 (CISPR32) BS EN/EN55032 (CISPR32) BS EN/EN61000-3-2	Class B Class A Class A		
SAFETY &		Conducted Radiated Harmonic Current Voltage Flicker	BS EN/EN55032 (CISPR32) BS EN/EN55032 (CISPR32) BS EN/EN61000-3-2 BS EN/EN61000-3-3	Class B Class A		
EMC		Conducted Radiated Harmonic Current Voltage Flicker BS EN/EN55035, BS EN/EN61000-6	BS EN/EN55032 (CISPR32) BS EN/EN55032 (CISPR32) BS EN/EN61000-3-2 BS EN/EN61000-3-3	Class B Class A Class A		
EMC		Conducted Radiated Harmonic Current Voltage Flicker BS EN/EN55035, BS EN/EN61000-6 Parameter	BS EN/EN55032 (CISPR32) BS EN/EN55032 (CISPR32) BS EN/EN61000-3-2 BS EN/EN61000-3-3 -2 Standard	Class B Class A Class A Test Level / Note		
EMC		Conducted Radiated Harmonic Current Voltage Flicker BS EN/EN55035, BS EN/EN61000-6	BS EN/EN55032 (CISPR32) BS EN/EN55032 (CISPR32) BS EN/EN61000-3-2 BS EN/EN61000-3-3 -2 Standard BS EN/EN61000-4-2	Class B Class A Class A Test Level / Note Level 3, 8KV air; Level 2, 4KV contact		
EMC		Conducted Radiated Harmonic Current Voltage Flicker BS EN/EN55035, BS EN/EN61000-6 Parameter	BS EN/EN55032 (CISPR32) BS EN/EN55032 (CISPR32) BS EN/EN61000-3-2 BS EN/EN61000-3-3 -2 Standard	Class B Class A Class A Test Level / Note		
EMC		Conducted Radiated Harmonic Current Voltage Flicker BS EN/EN55035, BS EN/EN61000-6 Parameter ESD	BS EN/EN55032 (CISPR32) BS EN/EN55032 (CISPR32) BS EN/EN61000-3-2 BS EN/EN61000-3-3 -2 Standard BS EN/EN61000-4-2	Class B Class A Class A Test Level / Note Level 3, 8KV air; Level 2, 4KV contact		
EMC	EMC EMISSION	Conducted Radiated Harmonic Current Voltage Flicker BS EN/EN55035, BS EN/EN61000-6 Parameter ESD Radiated	BS EN/EN55032 (CISPR32) BS EN/EN55032 (CISPR32) BS EN/EN61000-3-2 BS EN/EN61000-3-3 -2 Standard BS EN/EN61000-4-2 BS EN/EN61000-4-3	Class B Class A Class A Test Level / Note Level 3, 8KV air; Level 2, 4KV contact Level 3		
EMC	EMC EMISSION	Conducted Radiated Harmonic Current Voltage Flicker BS EN/EN55035, BS EN/EN61000-6 Parameter ESD Radiated EFT / Burst	BS EN/EN55032 (CISPR32) BS EN/EN55032 (CISPR32) BS EN/EN61000-3-2 BS EN/EN61000-3-3 -2 Standard BS EN/EN61000-4-2 BS EN/EN61000-4-3 BS EN/EN61000-4-4	Class B Class A Class A Test Level / Note Level 3, 8KV air; Level 2, 4KV contact Level 3 Level 3		
EMC	EMC EMISSION	Conducted Radiated Harmonic Current Voltage Flicker BS EN/EN55035, BS EN/EN61000-6 Parameter ESD Radiated EFT / Burst Surge	BS EN/EN55032 (CISPR32) BS EN/EN55032 (CISPR32) BS EN/EN61000-3-2 BS EN/EN61000-3-3 -2 Standard BS EN/EN61000-4-2 BS EN/EN61000-4-3 BS EN/EN61000-4-4 BS EN/EN61000-4-5	Class B Class A Class A Test Level / Note Level 3, 8KV air ; Level 2, 4KV contact Level 3 Level 3 Level 4, 2KV/Line-Line 4KV/Line-Earth		
SAFETY & EMC (Note 8)	EMC EMISSION	Conducted Radiated Harmonic Current Voltage Flicker BS EN/EN55035, BS EN/EN61000-6 Parameter ESD Radiated EFT / Burst Surge Conducted	BS EN/EN55032 (CISPR32) BS EN/EN55032 (CISPR32) BS EN/EN61000-3-2 BS EN/EN61000-3-3 -2 Standard BS EN/EN61000-4-2 BS EN/EN61000-4-3 BS EN/EN61000-4-4 BS EN/EN61000-4-5 BS EN/EN61000-4-6	Class B Class A Class A Class A Test Level / Note Level 3, 8KV air; Level 2, 4KV contact Level 3 Level 3 Level 4, 2KV/Line-Line 4KV/Line-Earth Level 3 Level 4 >95% dip 0.5 periods, 30% dip 25 period		
EMC Note 8)	EMC EMISSION EMC IMMUNITY	Conducted Radiated Harmonic Current Voltage Flicker BS EN/EN55035, BS EN/EN61000-6 Parameter ESD Radiated EFT / Burst Surge Conducted Magnetic Field Voltage Dips and Interruptions 483.3K hrs min. Telcordia SR-332 (BS EN/EN55032 (CISPR32) BS EN/EN55032 (CISPR32) BS EN/EN61000-3-2 BS EN/EN61000-3-3 -2 Standard BS EN/EN61000-4-2 BS EN/EN61000-4-3 BS EN/EN61000-4-4 BS EN/EN61000-4-5 BS EN/EN61000-4-6 BS EN/EN61000-4-8	Class B Class A Class A Class A Test Level / Note Level 3, 8KV air ; Level 2, 4KV contact Level 3 Level 3 Level 4, 2KV/Line-Line 4KV/Line-Earth Level 3 Level 4 >95% dip 0.5 periods, 30% dip 25 period >95% interruptions 250 periods		
EMC	EMC EMISSION EMC IMMUNITY	Conducted Radiated Harmonic Current Voltage Flicker BS EN/EN55035, BS EN/EN61000-6 Parameter ESD Radiated EFT / Burst Surge Conducted Magnetic Field Voltage Dips and Interruptions	BS EN/EN55032 (CISPR32) BS EN/EN55032 (CISPR32) BS EN/EN61000-3-2 BS EN/EN61000-3-3 -2 Standard BS EN/EN61000-4-2 BS EN/EN61000-4-3 BS EN/EN61000-4-4 BS EN/EN61000-4-5 BS EN/EN61000-4-6 BS EN/EN61000-4-8 BS EN/EN61000-4-11	Class B Class A Class A Class A Test Level / Note Level 3, 8KV air; Level 2, 4KV contact Level 3 Level 3 Level 4, 2KV/Line-Line 4KV/Line-Earth Level 3 Level 4 >95% dip 0.5 periods, 30% dip 25 period >95% interruptions 250 periods		

- 2. Ripple & noise are measured at 20MHz of bandwidth by using a 12" twisted pair-wire terminated with a 0.1uf & 47uf parallel capacitor.
- 3. Under parallel operation ripple of the output voltage may be higher than the SPEC at light load condition. It will go back to normal ripple level once the output load is more than 5%.

- Tolerance : includes set up tolerance, line regulation and load regulation.
 Derating may be needed under low input voltages. Please check the derating curve for more details.
 PV/PC functions when users are not operating on PMBus/CANBus. SVR functions when users are neither operating on PMBus/CANBus nor using PV/PC.
- 7. Output will shut down after O/P voltage is below < 80% of Vset for 5 sec, re-power on to recover.
- 8. The power supply is considered a component which will be installed into a final equipment. All the EMC tests are been executed by mounting the unit on a 720mm*360mm metal plate with 1mm of thickness. The final equipment must be re-confirmed that it still meets EMC directives. For guidance on how to perform these EMC tests, please refer to "EMI testing of component power supplies." (as available on http://www.meanwell.com)

 9. The ambient temperature derating of 3.5°C/1000m with fanless models and of 5°C/1000m with fan models for operating altitude higher than 2000m(6500ft).
- ** Product Liability Disclaimer : For detailed information, please refer to https://www.meanwell.com/serviceDisclaimer.aspx








■ Function Manual

1. Voltage Drop Compensation


- 1.1 Remote Sense
- ※ The Remote Sense compensates voltage drop on the load wiring up to 0.5V



① The +S signal should be connected to the positive terminal of the load whereas -S signal to the negative terminal.


1.2 Local Sense


The +S,-S have to be connected to the +V(signal),-V(signal), respectively, as the following diagram, in order to get the correct output voltage if Remote Sense is not used.




2. Output Voltage Programming (or, PV / remote voltage programming / remote adjust / margin programming / dynamic voltage trim)

※ In addition to the adjustment via the built-in potentiometer, the output voltage can be trimmed to 40~125% of the nominal voltage by applying EXTERNAL VOLTAGE.








- The rated current should change with the Output Voltage Programming accordingly.
- O For Remote Sense / Local Sense, please refer to "Voltage Drop Compensation" section.




3. Constant Current Level Programming (or, PC / remote current programming / dynamic current trim)

※ The constant current level can be trimmed to 20~100% of the rated current by applying EXTERNAL VOLTAGE.




- © For Remote Sense / Local Sense, please refer to "Voltage Drop Compensation" section.
- Output will shut down after O/P voltage is below < 80% of Vset for 5 sec, re-power on to recover.



4. Remote ON-OFF Control

The power supply can be turned ON/OFF individually or along with other units by using the "Remote ON-OFF" function.




Between Remote ON-OFF and +5V-AUX	Power Supply Status
Switch Short	ON
Switch Open	OFF

5.PMBus Communication Interface

RCP-1600 supports PMBus Rev. 1.1 with maximum 100KHz bus speed, allowing information reading, status monitoring, output trimming, etc. For details, please refer to the Function Manual.






※ LED Status Indicators

LED	Description	
Green	The power supply functions normally.	
Red	The LED will present a constant red light when the abnormal status (OTP, OLP, fan fail and charging timeout) arises.	
Red (Flashing) The LED will flash with the red light when the internal temperature reaches 60°C; under this condition, the unit still operates norm without entering OTP. (In the meantime, an alarm signal will be sent out through the PMBus interface.)		

※ Input / Output Connector Pin No. Assignment(CN1): Positronic PCIM34W13M400A1



Γ	Mating Housing	Positronic PCIM34W13F400A1
---	----------------	----------------------------

Pin No.	Function	Description	
1,2,3,4,6	-V	Negative output terminal.	
5,7,8,9,10	+V	Positive output terminal.	
11	+12V-AUX	Auxiliary voltage output, 10.8~13.2V, referenced to GND-AUX (pin 12). The maximum load current is 0.8A. This output has the built-in "Oring diodes" and is not controlled by the Remote ON/OFF controlled.	
12	GND-AUX	Auxiliary voltage output GND. The signal return is isolated from the output terminals (+V & -V).	
13	+5V-AUX	Auxiliary voltage output, 4.5~5.5V, referenced to <i>GND-AUX</i> (pin 12). The maximum load current is 0.3A. This output has the built-in "Oring diodes" and is not controlled by the <i>Remote ON/OFF</i> control.	
14	SCL	For PMBus model: Serial Clock used in the PMBus interface. (Note.2)	
14	CANL	For CANBus model: Data line used in CANBus interface. (Note.2)	
15	SDA	For PMBus model: Serial Data used in the PMBus interface. (Note.2)	
15	CANH	For CANBus model: Data line used in CANBus interface. (Note.2)	
High (3.5 ~ 5.5V): When the internal temperature exceeds the limit of temperature alarm, or when fan fails. 16 T-ALARM Low (-0.5 ~ 0.5V): When the internal temperature is normal, and when fan normally works. The maximum sourcing current is 10mA and only for output(Note.2)			
17	Remote ON-OFF		
18	DC-OK	High (3.5 ~ 5.5V): When the Vout ≦77%±5%. Low (-0.5 ~ 0.5V): When Vout ≧80% ±5%. The maximum sourcing current is 10mA and only for output. (Note.2)	
19	AC-OK	High (3.5 ~ 5.5V): When the input voltage is ≥87Vrms. Low (-0.5 ~ 0.5V): When the input voltage is ≤75Vrms. The maximum sourcing current is 10mA and only for output. (Note.2)	
20,21,22,23	A3,A2,A1,A0	PMBus / CANBus interface address lines. (Note.1)	
24,25	DB,DA	,DA Differential digital signal for parallel control. (Note.1)	
26	PC Connection for constant current level programming. (Note.1)		
27	PV	Connection for output voltage programming. (Note.1)	
28	+V (Signal)	Positive output voltage signal. It is for local sense; it cannot be connected directly to the load.	
29	-V (Signal) Negative output voltage signal. It is for local sense; and certain function reference; it cannot be connected directly to the load.		
30	+S	Positive sensing for remote sense.	
31	-S	Negative sensing for remote sense.	
32	FG	AC Ground connection.	
33	AC/L	AC Line connection.	
34	AC/N	AC Neutral connection.	

Note1: Non-isolated signal, referenced to [-V(signal)]. Note2: Isolated signal, referenced to GND-AUX.