

XGZP195 PRESSURE SENSOR

FEATURES

- Range: 0 ~ 10/50/100/200kPaG
- MEMS technology, Solid-state reliability
- Perfect replacement, Plug and Play.
- Calibrated mV analog output
- Working temp.: -30° C ~ $+125^{\circ}$ C(-22° F ~ $+257^{\circ}$ F)
- Gage pressure type(Positive&Negative Pressure)
- Easy to use and embed in OEM equipment



APPLICATIONS

- For medical and healthy equipment, e.g. Patient Monitoring, Infusion and Syringe Pumps, Anesthesia machines, Respirators and Ventilators, NPWT, DVT, Catheter, COPD Treatment, Kidney dialysis, Cupping& Cosmetology, Hospital beds, Massage device etc.
- For white goods and consumer electronics, e.g. Refrigerator, Printer, Humidifier, Washer/Dryer, Coffee machine, Dust collector or Cleaner, Robotic ,Sport equipment etc.
- For more fields, e.g. Digital display meter, Air pump, Process control, Pressure switching, HVAC and pneumatic device, Air flow monitor, Automation, Automative electronic, Intelligent fire control systemetc.

INTRODUCTION

XGZP195 is a surface mounting pressure sensor based on CFSensor silicon-glass based piezoresistive pressure sensor die. The sensor die is bonded on a substrate with a plastic cap and packaged in a 6-pin SIP housing. The built-in circuit calibrates and compensates the sensor's zero output, full-scale output, temperature drift and other parameters, and generates a high-precision standard voltage output signal proportional to the supply voltage.

The small size and high reliability of integration make this sensor a simple and economical choice for high volume application in a variety of industries. With standard SMD PIN, XGZP195 is easy for users to install by board mounting.

The XGZP195 pressure sensor is intended for use with non-corrosive gas or air. It is highly prohibited to choke the side of pressure diaphragm during actual application. Please consult us if a pressure medium other then air is to be used.



Electronic Performance

■ Power Supply: <16Vdc or 6.0mAdc

■ Input Impedance : $4kΩ \sim 6kΩ$ ■ Output Impedance : $4kΩ \sim 6kΩ$ ■ Insulation Resistor: 100MΩ,100VDC

Over Pressure: 2X Rated Pressure

Construction

■ Sensing Die: Silicon

■ Die Mounting Glue: Silicone Gel

■ Leading wire: Gold Wire

■ Package Housing: PPS(Phenylene sulfide),FR4

■ Pin: Silver Plated Copper■ Net Weight: Approx.5g

Environment Condition

■ Orientation: Deviate 90° from any direction, zero change ≤ 0.05%FS

■ Shock: No change at 10gRMS, (20 ~ 2000)Hz condition

■ Impact: 100g, 11ms■ Medium Compatibility:

Pressure side: air or gas compatible with silicone, silicone glue, epoxy glue or PPS

Reference side: dry air and non-corrosive gas compatible with PPS, silicon and silicone glue or

epoxy, gold, aluminum and silver.

Test Condition

■ Medium: Gas(Clean air and Non-corrosive gas)

■ Medium Temp: (25±1)°C/(77±1.8)°F

■ Environment Temp.: $(25\pm1)^{\circ}$ C/ $(77\pm1.8)^{\circ}$ F

■ Shock: 0.1g (1m/s2) Max■ Humidity: (50%±10%) RH

■ Power Supply: (10±0.005) VDC



SPECIFICATIONS


Speci	fications	Symbol	Min.	Тур.	Max	Unit
Pressure Range		Рор	10、50、100、200			kPa
FIESS	are Karige	РОР	1.45、7.25、14.5、29		29	PSI
Working Voltage		Vs	_	10	16	Vdc
Workir	ng Current	lo	_	6	_	mAdc
StorageT	emperature	Tstg	-30	25	+125	℃
Working	Working Temperature		-20	_	+100	℃
Bridge	Resistance	R_L	4.5	5	5.5	kΩ
Offset/Z	Zero Output	Voff	-1	0	+1	mV
FS Output(0~10kPa)		Vfss	24	25	26	mV
FS Output(0~50/100/200kPa)		Vfss	38.5	40	41.5	mV
	10kPa	- ΔV/ΔΡ	_	2.5	_	mV/kPa
Sensitivity	50kPa		_	0.8	_	
Sensitivity	100kPa		_	0.4	_	
	200kPa		_	0.2	_	
Linearity			-0.5	_	+0.5	%VFSS
Hysteresis			_	±0.15	_	%VFSS
TCO(Temp. Coefficient of Offset)		TCVOFF	-1.0	_	+1.0	mV
TCS(Temp. Coefficient of Span)		TCvfss	-2.0	_	+2.0	%VFSS
Response Time		T_{R}	_	2.5	_	ms
Long-term Stability(1000h)			_	±0.5	_	%FS

Note:


- 1 Sensor output is ratiometric within this specified excitation range. Operating the device above the specified excitation range may induce additional error due to sensor self-heating.
- 2 Full Scale Span (VFSS) is defined as the algebraic difference between the output voltage at full rated pressure and the output voltage at the minimum rated pressure.
- 3 Offset (Voff) is defined as the output voltage at the minimum rated pressure
- 4 Linearity: Output deviation from a straight line relationship with pressure, using end point method, over the specified pressure range.
- 5 Temperature Hysteresis: Output deviation at any temperature within the operating temperature range, after the temperature is cycled to and from the minimum or maximum operating temperature points, with zero differential pressure applied.
- 6 Pressure Hysteresis: Output deviation at any pressure within the specified range, when this pressure is cycled to and from the minimum or maximum rated pressure, at 25°C.
- 7 TcSpan: Output deviation at full rated pressure over the temperature range of 0 to 55°C, relative to 25°C.
- 8 TcOffset: Output deviation with minimum rated pressure applied, over the temperature range of 0 to 55°C, relative to 25°C
- 9 Response Time is defined as the time for the incremental change in the output to go from 10% to 90% of its final value when subjected to a specified step change in pressure
- 10 Offset stability is the product's output deviation when subjected to 1000 hours of Pulsed Pressure, Temperature Cycling with Test Condition.



DIMENSION (Unit:mm)



PIN CONNECTION&DEFINITION



Pin	1	2	3	4
Definition	GND	Vo+	VDD	Vo-

Symbol	Vdd	GND	Vo+	Vo-
Definition	Power +	GROUND	Output +	Output -

ORDER GUIDE

XGZP195	Piezo-resistive Pressure Sensor			
	Code	Range	100kPa=0.1mKp=750mmHg=10MH2O≈1bar≈14.5PSI	
	010	0 ~ 10kPa	Available for Negative pressure(-10 ~ 10kPa)	
	050	0 ~ 50kPa	Available for Negative pressure(-50 ~ 50kPa) Available for Negative pressure(-100 ~ 100kPa)	
	101	0 ~ 100kPa		
	201	0 ~ 200kPa	Available for Negative pressure(-190 ~ 200kPa)	
		Code		
		S	SOP Package	
			Code	
			G	Gauge Pressure Type
XGZP195	010	S	G	the whole spec.



OVERALL NOTES

Mounting


The following steps is for transmitting the air pressure to sensor after sensor soldering on PCB.

- ▼ Select the air pressure inlet flexiable pipe(recommended dia:3.0mm) that is firm enough to prevent the pressure leaks.
- ▼ Inlet pipe and atmosphere hole (at top of housing) can't be blocked with gel or glue etc,.
- ▼ Avoiding excessive external force operation

Soldering

Due to its small size, the thermal capacity of the pressure sensor is low. Therefore, take steps to minimize the effects of external heat. Damage and changes to characteristics may occur due to heat deformation. Use a non-corrosive resin type of flux. Since the pressure sensor is exposed to the atmosphere, do not allow flux to enter inside.

- ▼ Manual soldering
- ⊙ Raise the temperature of the soldering tip between 260 and 300°C/500 and 572°F (30 W) and solder within 5 seconds.
- ⊙The sensor output may vary if the load is applied on the terminal during soldering.
- ⊙ Keep the soldering tip clean.
- ▼ Reflow soldering (SMD Terminal)
- ⊙The recommended reflow temperature profile conditions are given below.



- ⊙We recommend the screen solder printing method as the method of cream.
- ⊙ Please refer to the recommended PC board specification diagram for the PC board foot pattern.
- \odot Self alignment may not always work as expected, therefore, please carefully the position of the terminals and pattern.
- ⊙ The temperature of the profile is assumed to be a value measured with the printed wiring board of the terminal neighborhood.
- ⊙ Please evaluate solderbility under the actual mounting conditions since welding and deformation of the pressure inlet port may occur due to heat stress depending on equipments or conditions.
- ▼ Rework soldering
- ⊙Complete rework at a time.
- ① Use a flattened soldering tip when performing rework on the solder bridge. Do not add the flux.
- Keep the soldering tip below the temperature described in the specifications.
- ▼ Avoid drop and rough handling as excessive force may deform the terminal and damage soldering characteristics.
- ▼ Keep the circuit board warpage within 0.05 mm of the full width of the sensor.
- ▼ After soldering, do not apply stress on the soldered part when cutting or bending the circuit board.
- ▼ Prevent human hands or metal pieces from contacting with the sensor terminal. Such contact may cause anomalous outlets as the terminal is exposed to the atmosphere.
- ▼ After soldering, prevent chemical agents from adhering to the sensor when applying coating to avoid insulation deterioration of the circuit board.



Connecting

- ▼ Correctly wire as in the connection diagram. Reverse connection may damage the product and degrade the performance.
- ▼ Do not use idle terminals(N/C) to prevent damages to the sensor.

Cleaning

- ▼ Since the pressure sensor is exposed to the atmosphere, do not allow cleaning fluid to enter inside.
- ▼ Avoid ultrasonic cleaning since this may cause breaks or disconnections in the wiring.

Environment

- ▼ Please avoid using or storing the pressure sensor in a place exposed to corrosive gases (such as the gases given off by organic solvents, sulfurous acid gas, hydrogen sulfides, etc.) which will adversely affect the performance of the pressure sensor chip.
- ▼ Since this pressure sensor does not have a water-proof construction, please do not use the sensor in a location where it may be sprayed with water, etc.
- ▼ Avoid using the pressure sensors in an environment where condensation may form. Furthermore, its output may fluctuate if any moisture adhering to it freezes.
- ▼ The pressure sensor is constructed in such a way that its output will fluctuate when it is exposed to light. Especially when pressure is to be applied by means of a transparent tube, take steps to prevent the pressure sensor chip from being exposed to light.
- ▼ Avoid using pressure sensor where it will be susceptible to ultrasonic or other high-frequency vibration.
- ▼ Please keep the sensors sealed using static shielding bags on storage. The PINs of sensor are plated by Ag. If the sensors expose to an atmosphere, the PINs will be black by oxidation, althought it wouldn't affect the sensor performance.

More Precautions

- ▼That using the wrong pressure range or mounting method may result in accidents.
- ▼ The only direct pressure medium you can use is air(25 % ~ 85 % %RH). The use of other media, in particular, corrosive gases (organic solvent based gases, sulfurous acid based gases, and hydrogen sulfide based gases, etc.) and media that contains heavy moisture or foreign substances will cause malfunction and damage. Please do not use them and check with CFSensor.
- ▼ The pressure sensor is positioned inside the pressure inlet. Never poke wires or other foreign matter through the pressure inlet since they may damage the sensor or block the inlet. Avoid use when the atmospheric pressure inlet is blocked.
- ▼ Use an operating pressure which is within the rated pressure range. Using a pressure beyond this range may cause damage.
- ▼ Since static charge can damage the pressure sensor, bear in mind the following handling precautions.
- ①When storing the pressure sensor, use a conductive material to short the pins or wrap the entire sensor in aluminum foil. Plastic containers should not be used to store or transport the sensor since they readily become charged.
- When using the pressure sensor, all the charged articles on the bench surface and the work personnel should be grounded so that any ambient static will be safely discharged.
- ▼ Based on the pressure involved, give due consideration to the securing of the pressure sensor DIP type and to the securing and selection of the inlet tube.



SAFETY NOTES

Using these sensors products may malfunction due to external interference and surges, therefore, please confirm the performance and quality in actual use. Just in case, please make a safety design on the device (fuse, circuit breaker, such as the installation of protection circuits, multiple devices, etc.), so it would not harm life, body, property, etc even a malfunction occurs.

To prevent injuries and accidents, please be sure to observe the following items:

- The driving current and voltage should be used below the rated value.
- Please follow the terminal connection diagram for wiring. Especially for the reverse connection of the power supply, it will cause an accident due to circuit damage such as heat, smoke, fire, etc.
- In order to ensure safety, especially for important uses, please be sure to consider double safety circuit configuration.
- Do not apply pressure above the maximum applied pressure. In addition, please be careful not to mix foreign matter into the pressure medium. Otherwise, the sensor will be discarded, or the media will blew out and cause an accident.
- Be careful when fixing the product and connecting the pressure inlet. Otherwise, accidents may occur due to sensor scattering and the blowing out of the media.
- Because the sensor PIN is sharp, please be careful not to hurt your body when using it.

[WARRANTY]

The information in this sheet has been carefully reviewed and is believed to be accurate; however, no responsibility is assumed for inaccuracies. Furthermore, this information does not convey to the purchaser of such devices any license under the patent rights to the manufacturer. CFSensor reserves the right to make changes without further notice to any product herein. CFSensor makes no warranty, representation or guarantee regarding the suitability of its product for any particular purpose, nor does CFSensor assume any liability arising out of the application or use of any product or circuit and specifically disclaims any and all liability, including without limitation consequential or incidental damages. Typical parameters can and do vary in different applications. All operating parameters must be validated for each customer application by customer's technical experts. CFSensor does not convey any license under its patent rights nor the rights of others.

[CONTACT]

CFSensor

14-15F/4Bldg High-Tech Park High-Tech Area Wuhu P.R.C.241000 Tel/Fax:+86 18226771331 Email:INFO@CFSensor.com